

# How to replace the batteries in your TEGH48 heater.


by Mario Raya

First open the service panel by loosening the philips head screw.

Open the panel so you can have access to the following parts:

- \*Battery pack
- \*Control module
- \*Gas valve





Notice the following components:

- \*Battery pack
- \*Control module
- \*Gas Valve Assembly

\*To remove the battery pack you'll need to gently press down on the battery pack to release it from the holder. Once the battery pack has been removed, you'll be able to open the holder and install fresh batteries.

for the M



**To open the battery pack, gently push on battery holder to open and remove old batteries.**

\*NOTE: Try not to use too much force when trying to release the cover. Pressing too hard can cause damage to cover or break the battery pack.

For any additional assistance, please contact Twin Eagles tech support @ 562-802-3488 or email: [service@twineaglesbbq.com](mailto:service@twineaglesbbq.com) .